

Intel® QuickAssist Technology Quick Start Guide

Step 1: Get QAT hardware

- For more details on Intel® QuickAssist Adapter 8950 Intel PCIe Express cards visit: <http://www.intel.com/content/dam/www/public/us/en/documents/product-briefs/quickassist-adapter-8950-brief.pdf>
- For details on 3rd party adapter solutions please contact your Intel Field Representative or visit the Network Builders Site: <https://networkbuilders.intel.com>

Step 2: Get acquainted with the available resources

- **Intel® QuickAssist Technology Main** - www.intel.com/quickassist
- **Intel® QuickAssist Technology 01.org Technical Collateral & Applications** - <https://01.org/intel-quickassist-technology>
- **To Learn how to use Intel® QuickAssist Technology and run example code, review our tutorial videos on Intel Developer Zone – Intel® QuickAssist Technology Technical Getting Started Tutorials** - <https://software.intel.com/en-us/networking/quickassist>

Step 3: Follow our Getting Started Guide

- Find the correct Getting Started Guide:
 - For released products: <https://01.org/intel-quickassist-technology>
 - For unreleased products: Contact your Intel Field Representative
- Follow the instructions to install the QAT software and run the performance sample code